

The Morphic M51 Series Timepiece

(MPH5101 – MPH5107)



Setting Instructions

- 1) Pull the crown out two clicks.
- 2) Rotate the crown counterclockwise until the date indicator(s) changes once.
- 3) Set the current time by rotating the crown counterclockwise;
 - for AM hours **do not** advance the hour hand past the 12 o'clock position,
 - for PM hours advance the hour hand past the 12 o'clock position **once**.
- 4) Push the crown in one click.
- 5) Set the current date by rotating the crown clockwise until the correct value is displayed.
- 6) Push the crown in one click to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures that the date indicators change at midnight rather than noon. If the date indicators are changing in the afternoon advance the hour hand one full rotation (12 hours), then reset the date indicators as necessary.

Tachymeter Functions

Start / Stop / Reset

- 1) Press Button A to start the timer, press again to stop.
- 2) Press Button B to reset the timer / hands.

Lap Tracking

- 1) Press Button A to start the timer.
- 2) Press Button B to pause the hands of the timers (tachymeter will continue running).
- 3) Press Button B to resume (timer hands will advance to current time).
- 4) To stop the timer press Button A (tachymeter and timer hands will stop), press again to resume.
- 5) To reset the timer press Button A to stop, then press Button B to reset.

Water Resistance Guidelines

Note: Manipulation of the crown or buttons while the watch is in contact with water will negate the rated water resistance as water penetration may occur.

Water Resistance Guidelines		
Rating	Submersible	Capacity of Resistance
No Marking	No	Splash/light contact only.
5ATM	No	Hand/dish washing.
10ATM	Yes	Low depth and short duration only.
20ATM	Yes	Short duration diving up to 5 meters.