

## The Simplify 4100 Series Timepiece

(SIM4101 – SIM4107)



### Setting Instructions

- 1) Pull the crown out.
- 2) Rotate the crown clockwise until the pointed end of the silver hand points at the current hour.
- 3) Rotate the crown clockwise until the pointed end of the red hand points at the current minute. \*
- 4) Push the crown in to its rest position to commence timekeeping.

### Water Resistance Guidelines

**3 ATM** – light contact and short duration resistance only. Not suitable for bathing, swimming, diving, or extended periods of contact. **Note:** manipulation of the crown while the watch is in contact with water will negate the rated water resistance as water penetration may occur.

\* Note: the SIM4103 has an orange minute hand.