

# The Elevon *Lindbergh* Timepiece

(ELE102-1 – ELE102-6)



## Setting Instructions

- 1) Pull the crown out one click.
- 2) Set the current time by rotating the crown clockwise. Reference the 24-hour sub dial to ensure AM / PM hours are observed accordingly (24-12 = AM, 12-24 = PM).
- 3) Push the crown in one click.
- 4) Set the current day of the week by pressing button A until the correct value is displayed.
- 5) Set the current date by pressing button B until the correct value is displayed.

**Note:** Setting the time to AM / PM accordingly ensures that the date indicators change at midnight rather than noon. If the date indicators have not changed by 4 AM, advance the hour hand one full rotation (12 hours), then reset the date indicators as necessary.

## Water Resistance Guidelines

**5 ATM** - may be submerged for short durations, in normal temperature fresh water only. Not suitable for bathing, swimming, watersports, or diving.

**Note:** Manipulation of the crown or buttons while the watch is in contact with water will negate the rated water resistance, as water penetration may occur.