

The Elevon *Gann* Timepiece

(ELE106-1 – ELE106-6)



Setting Instructions

- 1) Pull the crown out two clicks.
- 2) Rotate the crown counterclockwise until the day of the week indicator displays the current day of the week.
- 3) Set the current time as follows:
 - for AM hours, advance the hands directly to the current time,
 - for PM hours, advance the hour hand one full rotation (12 hours) *once*, prior to setting the time.
- 4) Push the crown in one click to the middle position.
- 5) Set the current date by rotating the crown clockwise until the correct value is displayed.
- 6) Push the crown in one click to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures that the date indicators change at midnight rather than noon. If the date indicators are changing in the afternoon advance the hour hand one full rotation (12 hours), then reset the date indicators as necessary.

Changing the Day of the Week Language (English / Spanish)

- 1) Pull the crown out two clicks.
- 2) Rotate the crown counterclockwise until the day of the week indicator advances to any day of the week in the desired language.
- 3) Rotate the crown clockwise until the hour hand makes one full rotation in the opposite direction.
- 4) Push the crown in two clicks.
- 5) Follow the steps above to set the watch.

Water Resistance Guidelines

5 ATM – may be submerged for short durations, in normal temperature fresh water only. Not suitable for bathing, swimming, watersports, or diving.

Note: manipulation of the crown while the watch is in contact with water will negate the rated water resistance as water penetration may occur.