

The Elevon Lear Timepiece

(ELE107-1 – ELE107-6)



Setting Instructions

- 1) Pull the crown out two clicks.
- 2) Rotate the crown clockwise until the day of the week indicator displays the correct value.
- 3) Set the current time by rotating the crown clockwise. Reference the 24-hour sub dial to ensure AM / PM hours are observed accordingly (24-12 = AM, 12-24 = PM).
- 4) Push the crown in one click.
- 5) Set the current date by rotating the crown counterclockwise until the correct value is displayed.
- 6) Push the crown in one click to commence timekeeping.

Note: Setting the time to AM / PM accordingly ensures that the date indicators change at midnight rather than noon. If the date indicators are changing in the afternoon, advance the hour hand one full rotation (12 hours), then reset the date indicators as necessary.

Water Resistance Guidelines

5 ATM – May be submerged for short durations, in normal temperature fresh water only. Not suitable for bathing, swimming, watersports, or diving.